

Cover round St sec



Scope of delivery

- Stainless steel body and mounting plate
- 2 x M3x6mm allen screws
- 1 x M3x12mm allen screw
- 2 x chipboard screws 4x35mm and dowels
- 1 x allen screw driver

Note

Ideal mounting height is approximately 135 cm (upper edge). Shape of our TOCA-home case is exactly aligned to this height.

Do not remove the screws applied to the mounting plate!

Mounting

- At first attach the mounting plate to the wall of your house using the provided chipboard screws and dowels. Ideal mounting height is 135 cm (upper edge). Therefore use the holes located on the left and on the right side of the stainless steel mounting plate.

(see fig. 1)




fig. 1

- Next attach the plastic mounting plate (provided with your ekey TOCAhome outside unit) to the stainless steel mounting plate in the holes, located on the top and on the bottom side of the stainless steel mounting plate (the mounting holes of both mounting plates are congruent). Use the two small allen screws for this purpose.

(see fig. 2 and fig. 3)




fig. 2




fig. 3

- Connect the ekey TOCAhome outside unit to the inside unit (see installation manual provided with your ekey TOCA-home set).

Now you can plug the outside unit to the plastic mounting plate and fix it using the small screw provided with ekey TOCAhome (see the hole on the lower side of the outside unit).




fig. 4



fig. 5

Take the stainless steel body and put it over the outside unit. The screws on the left and on the right side of the stainless steel mounting plate serve as mount for the stainless steel body.

(see fig. 4 and fig. 5)

- On the lower side of the stainless steel body you can see a small opening. Through this opening you can reach a big allen screw. To complete the mounting you have to turn this screw to the left(!) until the body is tightly fixed.